

Mounting instructions:

Adjust the width of the tow mirror's fixing frame (1) to the width of the original vehicle mirror.

Apply mirror arms (1) on original vehicle mirror.

Guide the rubber straps (2) of the tow mirror over the back of the original vehicle mirror and fix the buckles (3) of the rubber straps to the hooks (4) of the tow mirror's fixing frame. If the vehicle mirror is tapered, the rubber bands need to be cross mounted for a tight fit.

Adjust the length of the rubber straps (2-3), so these are tight fitted during their fixation.

When the fixing frame of tow mirror is tight fitted to the original vehicle mirror, adjust mirror head (5) and (eventual) extra arm to guarantee optimal visibility.

Have a nice journey.

